ENGINE ECU REMOVAL & POSTAL REPAIR INSTRUCTIONS

IVECO DAILY – GLOW PLUG / EDC FAULT REPAIR

IMPORTANT — PLEASE READ BEFORE REMOVING THE ECU

After purchasing the repair service, your **engine ECU must be removed from the vehicle and posted to Mobile Daily Service** for the repair to be carried out.

1. LOCATE THE ENGINE ECU

The engine ECU is located on the **passenger-side inner guard inside the engine bay** on the applicable IVECO Daily.

2. VEHICLES PRIOR TO 2014

On IVECO Daily vehicles **previous to 2014**, the **battery will need to be removed** to gain access to the ECU.

3. REMOVE THE ECU

Carefully remove the engine ECU from the vehicle. Take care not to damage the ECU, connectors, wiring or mounting points during removal.

4. MARK THE ECU — VERY IMPORTANT

Using a **BLACK TEXTA / PERMANENT MARKER**, clearly write the following information on the **REAR OF THE ECU**:

FULL NAME	_____

ORDER NUMBER	_____

Do not skip this step. Your full name and order number allow us to correctly identify your ECU when it arrives.

5. PACKAGE THE ECU

Package the ECU securely so it cannot move around or be damaged during transport. Protect the electrical connectors and ECU housing from impact, moisture and excessive movement.

6. POST THE ECU TO

MOBILE DAILY SERVICE
Unit 7, 4–6 Barry Road
Chipping Norton NSW 2170
AUSTRALIA

BEFORE YOU SEND IT

- ■ ECU removed from the vehicle
- ■ Battery removed first if the vehicle is pre-2014 and access requires it
- ■ Full name written on the rear of the ECU in black permanent marker
- ■ Order number written on the rear of the ECU in black permanent marker
- ■ ECU securely packaged
- ■ ECU posted to Mobile Daily Service, Unit 7, 4–6 Barry Road, Chipping Norton NSW 2170

PLEASE KEEP YOUR POSTING/TRACKING RECEIPT UNTIL YOUR ECU HAS BEEN RECEIVED.